PRODUCT: 12XXLED-5050 DRIVER REPLACEMENT CUSTOMER INSTRUCTIONS

PART DESCRIPTION:	EFFECTIVE DATE:
INSTRUCTIONS ON HOW TO REPLACE THE DRIVERS IN BOTH 12XXLED-5050 16L AND 32L CONFIGURATIONS	XXXX


IMPORTANT

⚠WARNING: TO AVOID FIRE, SHOCK, OR DEATH, TURN OFF AND LOCKOUT POWER BEFORE PERFORMING ANY MAINTENANCE.


⚠CAUTION: THIS FIXTURE MUST BE WIRED IN ACCORDANCE WITH THE NATIONAL ELECTRIC CODE AND ALL APPLICABLE LOCAL CODES. PROPER GROUNDING IS REQUIRED. ALL WORK SHOULD BE DONE BY A QUALIFIED ELECTRICIAN.

16L CONFIGURATION INSTRUCTIONS


STEP 01:
OPEN THE FRONT DOOR AS SHOWN.




STEP 02:
UNDO THE CLASPS.



STEP 03:
PULL OUT ENTIRE DRIVER ASSEMBLY AND DISCONNECT THE WIRES HOLDING IT IN.



STEP 04:
CONNECT THE NEW DRIVER ASSEMBLY TO THE EXISTING WIRES IN FIXTURE AND INSERT DRIVER ASSEMBLY BACK INTO FIXTURE AND SECURE WITH CLASPS. CLOSE THE DOOR.



REV	DESCRIPTION	ENGINEER	CHECKED BY	DATE	ECN #
A					

REVISION HISTORY

DRAWN mcentorcelli	DATE 11/15/2023	TITLE 12XXLED-5050 DRIVER REPLACEMENT	Sternberg
CHECKED	DATE		
THIRD ANGLE PROJECTION	SIZE A	DWG NO 12XXLED-5050	REV
		SCALE	SHEET 1 OF 1