

H-TRACK SYSTEM LED HEAD - 5 CCT SELECTABLE - ROUND & SQUARE LR43879, LR43881, LR43882, LR43883, LR43887, LR43888, LR43890, LR43891

IMPORTANT SAFETY INSTRUCTIONS

WHEN INSTALLING OR USING THE LIGHTING SYSTEM, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING:

1. READ ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.
2. DO NOT INSTALL THIS LIGHTING SYSTEM IN A DAMP OR WET LOCATION.
3. DO NOT CUT ANY TRACK SECTIONS.
4. DO NOT INSTALL ANY PART OR A TRACK SYSTEM LESS THAN FIVE (5) FEET ABOVE THE FLOOR.
5. DO NOT INSTALL ANY FIXTURE ASSEMBLY CLOSER THAN SIX (6) INCHES FROM ANY CURTAIN, OR SIMILAR COMBUSTIBLE MATERIAL.
6. DISCONNECT ELECTRICAL POWER BEFORE ADDING TO, OR CHARGING THE CONFIGURATION OF THE TRACK.
7. DO NOT ATTEMPT TO ENERGIZE ANYTHING OTHER THAN LIGHTING TRACK FIXTURES ON THE TRACK. TO REDUCE THE RISK OF FIRE AND ELECTRIC SHOCK, DO NOT ATTEMPT TO CONNECT POWER TOOLS, EXTENSION CORDS, APPLIANCES, AND THE LIKE TO THE TRACK.

INSTRUCTIONS

1. BEFORE INSTALLING THE TRACK HEAD, REFER TO THE TRACK INSTALLATION INSTRUCTIONS TO MAKE SURE THE TRACK HEAD AND THE TRACK ARE COMPATIBLE.
 2. TURN OFF SWITCH AT MAIN POWER SOURCE BEFORE INSTALLING ANY TRACK OR FITTING.
 3. PULL DOWN THE LOCKING LEVER AND INSERT "ADAPTER CONTACT" INTO THE SLOT IN THE TRACK.
 4. ROTATE THE ADAPTER CLOCKWISE 90° TO LOCKED POSITION.
- NOTE: POLARITY LINE OF TRACK HEAD (2 PRONG SIDE) MUST POINT TOWARDS THE POLARITY LINE ON THE TRACK (INTENDED LINE) WHEN INSTALLED.
5. ADJUST THE CCT SWITCH BEHIND TO SELECT THE APPROPRIATE COLOR TEMPERATURE.
 6. TO REMOVE, PRESS THE LOCKING LEVER ON THE TRACK ADAPTER AND TURN THE TRACK HEAD COUNTER CLOCKWISE 90°.

FOR USE WITH LUXRITE, TRACKRITE SYSTEM ONLY.

