

## 3" ADJUSTABLE CYLINDER LIGHT - 5CCT SELECT LR43700, LR43705

### IMPORTANT:

**READ ALL INSTRUCTIONS BEFORE INSTALLING FIXTURES. KEEP FOR FUTURE REFERENCE.**  
**SAFETY:** FOR YOUR SAFETY, THIS FIXTURE MUST BE WIRED IN ACCORDANCE TO LOCAL ELECTRICAL CODES AND ORDINANCES. ALL WORK SHOULD BE DONE BY A QUALIFIED ELECTRICIAN.

**WARNING:** TURN THE POWER OFF FROM ELECTRICAL PANEL BEFORE INSTALLATION OF MAINTENANCE.

**DO NOT MODIFY THIS FIXTURE.** ANY MODIFICATIONS MAY RENDER THE PRODUCT UNSAFE AND VOID WARRANTY.

THIS PRODUCT IS SUITABLE FOR WET LOCATIONS.

### FIXTURE INSTALLATION:

1. Measure distance from walls and mark position of fixture to be installed on the ceiling.
2. Carefully scribe hole template in accordance to cut hole size on desired location, male/female connectors and use switch to select Color Temperature.
3. Carefully cut hole in ceiling. **(Fig. 1)**
4. Wire the fixture accordingly.
5. Select desired color temperature.
6. Connect the hardwire box to cylinder light by connecting the quick male and female connectors. **(Fig. 2)**
7. Pass the hardwire box and attached cable through the hole and place on straight surface inside the ceiling hole. **(Fig. 3)**
8. Push the spring clip up towards the LED driver. **(Fig. 4)**
9. Push the fixture through the hole until the trim is flush with the ceiling. Spring clip will retract to hold trim in place. **(Fig. 5)**

