ACCORD LIGHTING

7108-7107-7110 GU-10


ASSEMBLY INSTRUCTIONS

USA & CANADA

WARNING!

Be sure electrical power is OFF before and during installation or maintenance.
The luminaire must be installed by a qualified electrician, in accordance with all applicable local codes.

Ensure that the rated luminaire voltage requirements are compatible with the available mains supply in which it will be installed.
All LEDS are included in your lamp. Never touch the LED surface with your bear hands as this may reduce the life of your LED.
Do not alter, relocate or remove any electrical component.



MOUNTING ON THE FIXTURE

Turn OFF the power before start the installation.

Carefully remove all parts from the box along with any protective paclking.

MAKING ELECTRICAL CONNECTIONS


1. Fit the articulator onto the end of the reinforcement bar and tighten it securely, ensuring that all components are firmly fastened and properly secured.

2. Install a Max 6W GU-10 MR16 LED Bulb (Not supplied) on the luminaire socket.
Install the deflector on the rod by fitting them together.

Install the deflector on the rod by fitting them together.

3. Use the switch on the power cord to turn the luminaire ON/OFF.

The luminaire is ready for use.



ATENTION!

FAILURE TO COMPLY WITH THESE INSTRUCTIONS MAY CAUSE ACCIDENTS AND LOSS OF PRODUCT WARRANTY.
Its recommended to read these instructions completely and carefully before proceeding.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

ACCORD Lighting guarantees coverage against manufacturing defects including electrical components and finishes, for a period of three years, under normal use, from the date of purchase. For warranty service, please contact your local dealer for further instructions. Proof of date of purchase will be required for validation of warranty service.

The responsability of the manufacturer regarding the product warranty is related to the correct observation of the instructions contained in this manual.
The manufacturer is not responsible for any damage to the product caused by accidents, alterations of any kind, improper usage or improper installation.
See the website for additional warranty details.

ACCORD Lighting reserves the right to change the dimensions and specifications contained in this manual without prior notice, in accordance with its policy of continuous product improvement. Please, contact the manufacturer if additional information is necessary. The illustrations in this manual are for guidance only and may vary in scale, dimensions and model details.

FABRICAÇÃO
ACCORD ILUMINAÇÃO
CNPJ: 01.754.342/0001-60

DISTRIBUÍÇÃO
L. MARTINKOSKI LTDA
CNPJ: 08.028.676/0001-03

DISTRIBUÍÇÃO
COMÉRCIO ATAC DE LUM BRAZIL LIGHTING
CNPJ: 27.286.700/0001-40

CONTATO: SAC@ACCORDILUMINACAO.COM.BR **TELEFONE:** (46) 3581-5962


7108-7109-7110 GU-10

INSTRUÇÕES DE MONTAGEM BRASIL

CUIDADO!

Para instalação ou manutenção certifique-se de que a rede elétrica esteja desligada.
Produtos elétricos devem ser instalados por profissionais habilitados de acordo com todas as normas locais aplicáveis.

ESTA LUMINÁRIA FOI DESENVOLVIDA PARA USO INTERNO OU ABRIGADO.
O local escolhido para a instalação deve suportar o peso do produto. Se necessário, fixe a luminária a elementos estruturais como vigas e lajes.
Instalações em locais especiais exigem fixações apropriadas.




Material: Lâmina natural de Madeira MDF Aço carbono
Peso 2.4 Kg

LIGAÇÃO ELÉTRICA

1. Encaixe o articulador na extremidade da ferragem e realize o aperto, certificando-se de que todos os componentes estejam firmemente fixados e devidamente seguros.
2. Instale uma lâmpada com base GU-10 MR16 (potência máxima 6W, não fornecida), no soquete interno da luminária.
   Com o encaixe do suporte feito, a sua lâmpada está instalada.
3. Use o interruptor elétrico para LIGAR / DESLIGAR.

Sua Luminária está pronta para uso.



ATENÇÃO!

O NÃO CUMPRIMENTO DAS INSTRUÇÕES CONTIDAS NESTE MANUAL PODERÁ CAUSAR ACIDENTES E PERDA DA GARANTIA DO PRODUTO.
É recomendado que se leia atentamente e por completo este manual de instruções antes de prosseguir com a instalação.

GUARDE ESTE MANUAL PARA CONSULTAS FUTURAS.

A ACCORD Iluminação garante cobertura contra defeitos de fabricação abrangendo componentes elétricos e acabamentos, pelo período de um ano, sob uso normal, a partir da data da compra. Para obter serviço de garantia, entre em contato com seu fornecedor local para obter mais instruções. Comprovação de data da compra será exigida para validação do serviço de garantia.

A responsabilidade do fabricante no que diz respeito à garantia da luminária está vinculada à correta observação das instruções contidas neste manual.
A ACCORD não se responsabiliza por qualquer dano ao produto causado por acidente, alterações de qualquer natureza, uso inadequado ou instalação inadequada. Confira mais detalhes sobre as condições de garantia no site.

A ACCORD Iluminação reserva-se do direito de alterar dimensões e especificações contidas neste manual sem aviso prévio, de acordo com sua política de melhoria contínua dos produtos. Por favor, entre em contato com o fabricante se houver necessidade de informações adicionais. As ilustrações contidas neste manual são apenas para orientação, podendo variar em escala, dimensões e detalhes do modelo.