

EDGE LED LIGHT PANEL

EDGE-11-WH

**IMPORTANT:** Read all instructions before installing fixtures. Retain for future reference. Suitable for continuous row mounting.

**SAFETY:** For your safety, this fixture must be wired in accordance to local electrical codes and ordinances. All work should be done by a qualified electrician.

**WARNING:** Make certain power is OFF from the electrical panel before starting installation or attempting any maintenance. Indoor installation only.

### **ELECTRICAL CONNECTIONS:**

MAXIMUM OF FOUR 12 AWG THROUGH BRANCH CIRCUIT Conductor Suitable for 90°C permitted in Box (2 Wires in And 2 Wires Out).

MAXIMUM OF SIX 14 AWG THROUGH BRANCH CIRCUIT Conductor Suitable for 90°C Permitted in Box (3 Wires in And 3 Wires Out).

- Make sure that the power from the main panel is switched off before starting any installation or maintenance of electrical fixtures.
- 2. Remove the cover on the junction box.
- Bring in a power supply line through one of the knockouts located closest to the input module [Fig. 1]. Wire connector required (supplied by others).
- 4. Connect the green (or bare copper) wire to the ground screw (located in the middle of the junction box [Fig. 2].
- Connect the white wire to the Neutral (N) port of the input module [Fig. 2].
- Connect the black wire to the Live (L) port of the input module [Fig. 2].
- 7. Replace the junction box cover back in place.
- Use the selector tab on the side of the driver/junction box to select color temperature (preset at 3500 K) [Fig. 3].
- 9. Secure driver to structure using the attached mounting plate.


### INSTALLATION INSTRUCTIONS:


- 1. Hold the LED panel  $45^{\circ}$  in relation to the T-bar direction (light side should be facing downwards).
- Push panel through the T-bar opening [Fig. 4].
  Adjust the LED panel so that the outer edge is sitting flush in the T-bars.
- Rotate support clips 180°. Make sure that the locking clip is secured to the groove on the fixture [Fig. 5].
- Bend the support clips 90° upwards, then bend 90° outwards until the tips of the support clips are positioned above the T-bars [Fig. 5].
- Use support cables (supplied by others) to secure the fixture to the structure (use the hole at the top of the support clips) [Fig. 6].
- Connect the EDGE panel to the driver using the DC 2.1 twist-and-lock connector [Fig. 7].
- Place ceiling tile on top of the EDGE panel. Make sure to cut 1.5" off of one of the corners to allow the low voltage connection wires to pass through [Fig. 8].
- 9. Turn the power back on from the main panel.





### Scan QR code for instructional video


Scannez le code QR pour la vidéo d'instructions




















Liteline Corporation Copyright © 2021 All rights reserved. Telephone 416.996.1856 1.866.730.7704 Fax 905.709.5255 1.888.738.9736



EDGE LED LIGHT PANEL

EDGE-12-WH

**IMPORTANT:** Read all instructions before installing fixtures. Retain for future reference. Suitable for continuous row mounting.

**SAFETY:** For your safety, this fixture must be wired in accordance to local electrical codes and ordinances. All work should be done by a qualified electrician.

**WARNING:** Make certain power is OFF from the electrical panel before starting installation or attempting any maintenance. Indoor installation only.

### **ELECTRICAL CONNECTIONS:**

MAXIMUM OF FOUR 12 AWG THROUGH BRANCH CIRCUIT Conductor Suitable for 90°C permitted in Box (2 Wires in And 2 Wires Out).

MAXIMUM OF SIX 14 AWG THROUGH BRANCH CIRCUIT Conductor Suitable for 90°C Permitted in Box (3 Wires in And 3 Wires Out).

- Make sure that the power from the main panel is switched off before starting any installation or maintenance of electrical fixtures.
- 2. Remove the cover on the junction box.
- Bring in a power supply line through one of the knockouts located closest to the input module [Fig. 1]. Wire connector required (supplied by others).
- 4. Connect the green (or bare copper) wire to the ground screw (located in the middle of the junction box [Fig. 2].
- Connect the white wire to the Neutral (N) port of the input module [Fig. 2].
- Connect the black wire to the Live (L) port of the input module [Fig. 2].
- 7. Replace the junction box cover back in place.
- Use the selector tab on the side of the driver/junction box to select color temperature (preset at 3500 K) [Fig. 3].
- 9. Secure driver to structure using the attached mounting plate.


### **INSTALLATION INSTRUCTIONS:**


- 1. Hold the LED panel  $45^{\circ}$  in relation to the T-bar direction (light side should be facing downwards).
- Push panel through the T-bar opening [Fig. 4].
  Adjust the LED panel so that the outer edge is sitting flush in the T-bars.
- Rotate support clips 180°. Make sure that the locking clip is secured to the groove on the fixture [Fig. 5].
- Bend the support clips 90° upwards, then bend 90° outwards until the tips of the support clips are positioned above the T-bars [Fig. 5].
- Use support cables (supplied by others) to secure the fixture to the structure (use the hole at the top of the support clips) [Fig. 6].
- Connect the EDGE panel to the driver using the DC 2.1 twist-and-lock connector [Fig. 7].
- Place ceiling tile on top of the EDGE panel. Make sure to cut 1.5" off of one of the corners to allow the low voltage connection wires to pass through [Fig. 8].
- 9. Turn the power back on from the main panel.





### Scan QR code for instructional video


Scannez le code QR pour la vidéo d'instructions




















Liteline Corporation Copyright © 2021 All rights reserved. Telephone 416.996.1856 1.866.730.7704 Fax 905.709.5255 1.888.738.9736



EDGE LED LIGHT PANEL

EDGE-14-WH

**IMPORTANT:** Read all instructions before installing fixtures. Retain for future reference. Suitable for continuous row mounting.

**SAFETY:** For your safety, this fixture must be wired in accordance to local electrical codes and ordinances. All work should be done by a qualified electrician.

**WARNING:** Make certain power is OFF from the electrical panel before starting installation or attempting any maintenance. Indoor installation only.

### **ELECTRICAL CONNECTIONS:**

MAXIMUM OF FOUR 12 AWG THROUGH BRANCH CIRCUIT Conductor Suitable for 90°C permitted in Box (2 Wires in And 2 Wires Out).

MAXIMUM OF SIX 14 AWG THROUGH BRANCH CIRCUIT Conductor Suitable for 90°C Permitted in Box (3 Wires in And 3 Wires Out).

- Make sure that the power from the main panel is switched off before starting any installation or maintenance of electrical fixtures.
- 2. Remove the cover on the junction box.
- Bring in a power supply line through one of the knockouts located closest to the input module [Fig. 1]. Wire connector required (supplied by others).
- 4. Connect the green (or bare copper) wire to the ground screw (located in the middle of the junction box [Fig. 2].
- Connect the white wire to the Neutral (N) port of the input module [Fig. 2].
- Connect the black wire to the Live (L) port of the input module [Fig. 2].
- 7. Replace the junction box cover back in place.
- Use the selector tabs on the side of the driver/junction box to select wattage (preset at highest wattage) and color temperature (preset at 3500 K) [Fig. 3].
- 9. Secure driver to structure using the attached mounting plate.


#### INSTALLATION INSTRUCTIONS:


- 1. Hold the LED panel 45° in relation to the T-bar direction (light side should be facing downwards).
- 2. Push panel through the T-bar opening [Fig. 4].
- 3. Adjust the LED panel so that the outer edge is sitting flush in the T-bars.
- Rotate support clips 180°. Make sure that the locking clip is secured to the groove on the fixture [Fig. 5].
   Bend the support clips 90° upwards, then bend 90°
- Bend the support clips 90° upwards, then bend 90° outwards until the tips of the support clips are positioned above the T-bars [Fig. 5].
- Use support cables (supplied by others) to secure the fixture to the structure (use the hole at the top of the support clips) [Fig. 6].
- Connect the EDGE panel to the driver using the DC 2.1 twist-and-lock connector [Fig. 7].
- 8. Place ceiling tile on top of the EDGE panel. Make sure to cut 1.5" off of one of the corners to allow the low voltage connection wires to pass through [Fig. 8].
- 9. Turn the power back on from the main panel.





### Scan QR code for instructional video


Scannez le code QR pour la vidéo d'instructions




















Liteline Corporation Copyright © 2021 All rights reserved. Telephone 416.996.1856 1.866.730.7704 Fax 905.709.5255 1.888.738.9736



EDGE LED LIGHT PANEL

EDGE-22-WH

**IMPORTANT:** Read all instructions before installing fixtures. Retain for future reference. Suitable for continuous row mounting.

**SAFETY:** For your safety, this fixture must be wired in accordance to local electrical codes and ordinances. All work should be done by a qualified electrician.

**WARNING:** Make certain power is OFF from the electrical panel before starting installation or attempting any maintenance. Indoor installation only.

### **ELECTRICAL CONNECTIONS:**

MAXIMUM OF FOUR 12 AWG THROUGH BRANCH CIRCUIT Conductor Suitable for 90°C permitted in Box (2 Wires in And 2 Wires Out).

MAXIMUM OF SIX 14 AWG THROUGH BRANCH CIRCUIT CONDUCTOR SUITABLE FOR 90°C PERMITTED IN BOX (3 WIRES IN AND 3 WIRES OUT).

- Make sure that the power from the main panel is switched off before starting any installation or maintenance of electrical fixtures.
- 2. Remove the cover on the junction box.
- Bring in a power supply line through one of the knockouts located closest to the input module [Fig. 1]. Wire connector required (supplied by others).
- 4. Connect the green (or bare copper) wire to the ground screw (located in the middle of the junction box [Fig. 2].
- Connect the white wire to the Neutral (N) port of the input module [Fig. 2].
- Connect the black wire to the Live (L) port of the input module [Fig. 2].
- 7. Replace the junction box cover back in place.
- Use the selector tabs on the side of the driver/junction box to select wattage (preset at highest wattage) and color temperature (preset at 3500 K) [Fig. 3].
- 9. Secure driver to structure using the attached mounting plate.


#### INSTALLATION INSTRUCTIONS:


- 1. Hold the LED panel 45° in relation to the T-bar direction (light side should be facing downwards).
- 2. Push panel through the T-bar opening [Fig. 4].
- 3. Adjust the LED panel so that the outer edge is sitting flush in the T-bars.
- Rotate support clips 180°. Make sure that the locking clip is secured to the groove on the fixture [Fig. 5].
   Bend the support clips 90° upwards, then bend 90°
- Bend the support clips 90° upwards, then bend 90° outwards until the tips of the support clips are positioned above the T-bars [Fig. 5].
- Use support cables (supplied by others) to secure the fixture to the structure (use the hole at the top of the support clips) [Fig. 6].
- Connect the EDGE panel to the driver using the DC 2.1 twist-and-lock connector [Fig. 7].
- 8. Place ceiling tile on top of the EDGE panel. Make sure to cut 1.5" off of one of the corners to allow the low voltage connection wires to pass through [Fig. 8].
- 9. Turn the power back on from the main panel.





### Scan QR code for instructional video


Scannez le code QR pour la vidéo d'instructions




















Liteline Corporation Copyright © 2021 All rights reserved. Telephone 416.996.1856 1.866.730.7704 Fax 905.709.5255 1.888.738.9736



EDGE LED LIGHT PANEL

EDGE-24-WH

**IMPORTANT:** Read all instructions before installing fixtures. Retain for future reference. Suitable for continuous row mounting.

**SAFETY:** For your safety, this fixture must be wired in accordance to local electrical codes and ordinances. All work should be done by a qualified electrician.

**WARNING:** Make certain power is OFF from the electrical panel before starting installation or attempting any maintenance. Indoor installation only.

### **ELECTRICAL CONNECTIONS:**

MAXIMUM OF FOUR 12 AWG THROUGH BRANCH CIRCUIT Conductor Suitable for 90°C permitted in Box (2 Wires in And 2 Wires Out).

MAXIMUM OF SIX 14 AWG THROUGH BRANCH CIRCUIT Conductor Suitable for 90°C Permitted in Box (3 Wires in And 3 Wires Out).

- Make sure that the power from the main panel is switched off before starting any installation or maintenance of electrical fixtures.
- 2. Remove the cover on the junction box.
- Bring in a power supply line through one of the knockouts located closest to the input module [Fig. 1]. Wire connector required (supplied by others).
- 4. Connect the green (or bare copper) wire to the ground screw (located in the middle of the junction box [Fig. 2].
- Connect the white wire to the Neutral (N) port of the input module [Fig. 2].
- Connect the black wire to the Live (L) port of the input module [Fig. 2].
- 7. Replace the junction box cover back in place.
- Use the selector tabs on the side of the driver/junction box to select wattage (preset at highest wattage) and color temperature (preset at 3500 K) [Fig. 3].
- 9. Secure driver to structure using the attached mounting plate.


#### INSTALLATION INSTRUCTIONS:


- 1. Hold the LED panel 45° in relation to the T-bar direction (light side should be facing downwards).
- 2. Push panel through the T-bar opening [Fig. 4].
- 3. Adjust the LED panel so that the outer edge is sitting flush in the T-bars.
- Rotate support clips 180°. Make sure that the locking clip is secured to the groove on the fixture [Fig. 5].
   Bend the support clips 90° upwards, then bend 90°
- Bend the support clips 90° upwards, then bend 90° outwards until the tips of the support clips are positioned above the T-bars [Fig. 5].
- Use support cables (supplied by others) to secure the fixture to the structure (use the hole at the top of the support clips) [Fig. 6].
- Connect the EDGE panel to the driver using the DC 2.1 twist-and-lock connector [Fig. 7].
- 8. Place ceiling tile on top of the EDGE panel. Make sure to cut 1.5" off of one of the corners to allow the low voltage connection wires to pass through [Fig. 8].
- 9. Turn the power back on from the main panel.





### Scan QR code for instructional video


Scannez le code QR pour la vidéo d'instructions




















Liteline Corporation Copyright © 2021 All rights reserved. Telephone 416.996.1856 1.866.730.7704 Fax 905.709.5255 1.888.738.9736



EDGE LED LIGHT PANEL

EDGE-26-WH

**IMPORTANT:** Read all instructions before installing fixtures. Retain for future reference. Suitable for continuous row mounting.

**SAFETY:** For your safety, this fixture must be wired in accordance to local electrical codes and ordinances. All work should be done by a qualified electrician.

**WARNING:** Make certain power is OFF from the electrical panel before starting installation or attempting any maintenance. Indoor installation only.

### **ELECTRICAL CONNECTIONS:**

MAXIMUM OF FOUR 12 AWG THROUGH BRANCH CIRCUIT Conductor Suitable for 90°C permitted in Box (2 Wires in And 2 Wires Out).

MAXIMUM OF SIX 14 AWG THROUGH BRANCH CIRCUIT Conductor Suitable for 90°C Permitted in Box (3 Wires in And 3 Wires Out).

- Make sure that the power from the main panel is switched off before starting any installation or maintenance of electrical fixtures.
- 2. Remove the cover on the junction box.
- Bring in a power supply line through one of the knockouts located closest to the input module [Fig. 1]. Wire connector required (supplied by others).
- 4. Connect the green (or bare copper) wire to the ground screw (located in the middle of the junction box [Fig. 2].
- 5. Connect the white wire to the Neutral (N) port of the input module [Fig. 2].
- 6. Connect the black wire to the Live (L) port of the input module [Fig. 2].
- 7. Replace the junction box cover back in place.
- Use the selector tabs on the side of the driver/junction box to select wattage (preset at highest wattage) and color temperature (preset at 3500 K) [Fig. 3].
- 9. Secure driver to structure using the attached mounting plate.


#### INSTALLATION INSTRUCTIONS:


- 1. Hold the LED panel 45° in relation to the T-bar direction (light side should be facing downwards).
- 2. Push panel through the T-bar opening [Fig. 4].
- 3. Adjust the LED panel so that the outer edge is sitting flush in the T-bars.
- Rotate support clips 180°. Make sure that the locking clip is secured to the groove on the fixture [Fig. 5].
   Bend the support clips 90° upwards, then bend 90°
- Bend the support clips 90° upwards, then bend 90° outwards until the tips of the support clips are positioned above the T-bars [Fig. 5].
- Use support cables (supplied by others) to secure the fixture to the structure (use the hole at the top of the support clips) [Fig. 6].
- Connect the EDGE panel to the driver using the DC 2.1 twist-and-lock connector [Fig. 7].
- 8. Place ceiling tile on top of the EDGE panel. Make sure to cut 1.5" off of one of the corners to allow the low voltage connection wires to pass through [Fig. 8].
- 9. Turn the power back on from the main panel.





### Scan QR code for instructional video


Scannez le code QR pour la vidéo d'instructions




















Liteline Corporation Copyright © 2021 All rights reserved. Telephone 416.996.1856 1.866.730.7704 Fax 905.709.5255 1.888.738.9736



EDGE LED LIGHT PANEL

EDGE-33-WH

**IMPORTANT:** Read all instructions before installing fixtures. Retain for future reference. Suitable for continuous row mounting.

**SAFETY:** For your safety, this fixture must be wired in accordance to local electrical codes and ordinances. All work should be done by a qualified electrician.

**WARNING:** Make certain power is OFF from the electrical panel before starting installation or attempting any maintenance. Indoor installation only.

### **ELECTRICAL CONNECTIONS:**

MAXIMUM OF FOUR 12 AWG THROUGH BRANCH CIRCUIT Conductor Suitable for 90°C permitted in Box (2 Wires in And 2 Wires Out).

MAXIMUM OF SIX 14 AWG THROUGH BRANCH CIRCUIT Conductor Suitable for 90°C Permitted in Box (3 Wires in And 3 Wires Out).

- Make sure that the power from the main panel is switched off before starting any installation or maintenance of electrical fixtures.
- 2. Remove the cover on the junction box.
- Bring in a power supply line through one of the knockouts located closest to the input module [Fig. 1]. Wire connector required (supplied by others).
- 4. Connect the green (or bare copper) wire to the ground screw (located in the middle of the junction box [Fig. 2].
- 5. Connect the white wire to the Neutral (N) port of the input module [Fig. 2].
- 6. Connect the black wire to the Live (L) port of the input module [Fig. 2].
- 7. Replace the junction box cover back in place.
- Use the selector tabs on the side of the driver/junction box to select wattage (preset at highest wattage) and color temperature (preset at 3500 K) [Fig. 3].
- 9. Secure driver to structure using the attached mounting plate.


#### INSTALLATION INSTRUCTIONS:


- 1. Hold the LED panel 45° in relation to the T-bar direction (light side should be facing downwards).
- 2. Push panel through the T-bar opening [Fig. 4].
- 3. Adjust the LED panel so that the outer edge is sitting flush in the T-bars.
- Rotate support clips 180°. Make sure that the locking clip is secured to the groove on the fixture [Fig. 5].
   Bend the support clips 90° upwards, then bend 90°
- Bend the support clips 90° upwards, then bend 90° outwards until the tips of the support clips are positioned above the T-bars [Fig. 5].
- Use support cables (supplied by others) to secure the fixture to the structure (use the hole at the top of the support clips) [Fig. 6].
- Connect the EDGE panel to the driver using the DC 2.1 twist-and-lock connector [Fig. 7].
- Place ceiling tile on top of the EDGE panel. Make sure to cut 1.5" off of one of the corners to allow the low voltage connection wires to pass through [Fig. 8].
- 9. Turn the power back on from the main panel.





### Scan QR code for instructional video


Scannez le code QR pour la vidéo d'instructions




















Liteline Corporation Copyright © 2021 All rights reserved. Telephone 416.996.1856 1.866.730.7704 Fax 905.709.5255 1.888.738.9736



EDGE LED LIGHT PANEL

EDGE-36-WH

**IMPORTANT:** Read all instructions before installing fixtures. Retain for future reference. Suitable for continuous row mounting.

**SAFETY:** For your safety, this fixture must be wired in accordance to local electrical codes and ordinances. All work should be done by a qualified electrician.

**WARNING:** Make certain power is OFF from the electrical panel before starting installation or attempting any maintenance. Indoor installation only.

### **ELECTRICAL CONNECTIONS:**

MAXIMUM OF FOUR 12 AWG THROUGH BRANCH CIRCUIT Conductor Suitable for 90°C permitted in Box (2 Wires in And 2 Wires Out).

MAXIMUM OF SIX 14 AWG THROUGH BRANCH CIRCUIT CONDUCTOR SUITABLE FOR 90°C PERMITTED IN BOX (3 WIRES IN AND 3 WIRES OUT).

- Make sure that the power from the main panel is switched off before starting any installation or maintenance of electrical fixtures.
- 2. Remove the cover on the junction box.
- Bring in a power supply line through one of the knockouts located closest to the input module [Fig. 1]. Wire connector required (supplied by others).
- 4. Connect the green (or bare copper) wire to the ground screw (located in the middle of the junction box [Fig. 2].
- Connect the white wire to the Neutral (N) port of the input module [Fig. 2].
- Connect the black wire to the Live (L) port of the input module [Fig. 2].
- 7. Replace the junction box cover back in place.
- Use the selector tabs on the side of the driver/junction box to select wattage (preset at highest wattage) and color temperature (preset at 3500 K) [Fig. 3].
- 9. Secure driver to structure using the attached mounting plate.


#### INSTALLATION INSTRUCTIONS:


- 1. Hold the LED panel 45° in relation to the T-bar direction (light side should be facing downwards).
- 2. Push panel through the T-bar opening [Fig. 4].
- 3. Adjust the LED panel so that the outer edge is sitting flush in the T-bars.
- Rotate support clips 180°. Make sure that the locking clip is secured to the groove on the fixture [Fig. 5].
   Bend the support clips 90° upwards, then bend 90°
- Bend the support clips 90° upwards, then bend 90° outwards until the tips of the support clips are positioned above the T-bars [Fig. 5].
- Use support cables (supplied by others) to secure the fixture to the structure (use the hole at the top of the support clips) [Fig. 6].
- Connect the EDGE panel to the driver using the DC 2.1 twist-and-lock connector [Fig. 7].
- 8. Place ceiling tile on top of the EDGE panel. Make sure to cut 1.5" off of one of the corners to allow the low voltage connection wires to pass through [Fig. 8].
- 9. Turn the power back on from the main panel.





### Scan QR code for instructional video


Scannez le code QR pour la vidéo d'instructions




















Liteline Corporation Copyright © 2021 All rights reserved. Telephone 416.996.1856 1.866.730.7704 Fax 905.709.5255 1.888.738.9736



EDGE LED LIGHT PANEL

### EDGE-44-WH

**IMPORTANT:** Read all instructions before installing fixtures. Retain for future reference. Suitable for continuous row mounting.

**SAFETY:** For your safety, this fixture must be wired in accordance to local electrical codes and ordinances. All work should be done by a qualified electrician.

**WARNING:** Make certain power is OFF from the electrical panel before starting installation or attempting any maintenance. Indoor installation only.

### **ELECTRICAL CONNECTIONS:**

MAXIMUM OF FOUR 12 AWG THROUGH BRANCH CIRCUIT Conductor Suitable for 90°C permitted in Box (2 Wires in And 2 Wires Out).

MAXIMUM OF SIX 14 AWG THROUGH BRANCH CIRCUIT Conductor Suitable for 90°C Permitted in Box (3 Wires in And 3 Wires Out).

- Make sure that the power from the main panel is switched off before starting any installation or maintenance of electrical fixtures.
- 2. Remove the cover on the junction box.
- Bring in a power supply line through one of the knockouts located closest to the input module [Fig. 1]. Wire connector required (supplied by others).
- 4. Connect the green (or bare copper) wire to the ground screw (located in the middle of the junction box [Fig. 2].
- Connect the white wire to the Neutral (N) port of the input module [Fig. 2].
- Connect the black wire to the Live (L) port of the input module [Fig. 2].
- 7. Replace the junction box cover back in place.
- Use the selector tabs on the side of the driver/junction box to select wattage (preset at highest wattage) and color temperature (preset at 3500 K) [Fig. 3].
- 9. Secure driver to structure using the attached mounting plate.


#### INSTALLATION INSTRUCTIONS:


- 1. Hold the LED panel 45° in relation to the T-bar direction (light side should be facing downwards).
- 2. Push panel through the T-bar opening [Fig. 4].
- 3. Adjust the LED panel so that the outer edge is sitting flush in the T-bars.
- Rotate support clips 180°. Make sure that the locking clip is secured to the groove on the fixture [Fig. 5].
   Bend the support clips 90° upwards, then bend 90°
- Bend the support clips 90° upwards, then bend 90° outwards until the tips of the support clips are positioned above the T-bars [Fig. 5].
- Use support cables (supplied by others) to secure the fixture to the structure (use the hole at the top of the support clips) [Fig. 6].
- Connect the EDGE panel to the driver using the DC 2.1 twist-and-lock connector [Fig. 7].
- Place ceiling tile on top of the EDGE panel. Make sure to cut 1.5" off of one of the corners to allow the low voltage connection wires to pass through [Fig. 8].
- 9. Turn the power back on from the main panel.





### Scan QR code for instructional video


Scannez le code QR pour la vidéo d'instructions




















Liteline Corporation Copyright © 2022 All rights reserved. Telephone 416.996.1856 1.866.730.7704 Fax 905.709.5255 1.888.738.9736

## **Liteline** RECESSED LIGHTING • LUMINAIRE ENCASTRE 9/16" EDGE ADAPTER

**ADAPTATEUR POUR EDGE 9/16 PO** 

Série P-EDGE-xx-WRB Series

### EN

**IMPORTANT:** Read all instructions before installing fixtures. Retain for future reference.

**SAFETY:** All electrical work should be done by a qualified electrician in accordance to local electrical codes and ordinances.

**WARNING:** Make certain power is OFF from the electrical panel before starting installation or attempting any maintenance. Indoor installation only.

### **INSTALLATION INSTRUCTIONS:**

Align the 9/16" adapter with the EDGE fixture and place it under, then hold them  $45^{\circ}$  in relation to the T-bar direction (light side should be facing downwards) and push panel through the T-bar opening. 9/16" Adapter lip should be sandwiched by the EDGE fixture and the T-bars.

### FR

**IMPORTANT :** Lire toutes les instructions avant d'installer les appareils. Conserver pour référence future.


**SÉCURITÉ**: Pour votre sécurité, cet appareil doit être câble conformément aux codes et règlements électriques locaux. Tout travail doit être effectué par un électricien qualifié.

**AVERTISSEMENT :** Un électricien compétent doit réaliser tous les travaux électriques en conformité avec les codes et décrets locaux en matière d'électricité.

### **INSTRUCTIONS DE MONTAGE :**

Alignez l'adaptateur 9/16 po avec le luminaire EDGE et placez-le dessous, puis maintenez-les à 45 ° par rapport à la direction de la barre en T (côté de la lumière doit être orientée vers le bas) et poussez le panneau à travers l'ouverture de la barre en T. La lèvre de l'adaptateur 9/16 po doit être prise en sandwich par le luminaire EDGE et les barres en T.

Adapter	Compatible Panel / Panneau Compatible
P-EDGE-14-WRB	LEDP-14-WH
P-EDGE-22-WRB	LEDP-22-WH
P-EDGE-24-WRB	LEDP-24-WH
P-EDGE-44-WRB	LEDP-44-WH



### Liteline Corporation Copyright © 2021 All rights reserved.

Telephone 416.996.1856 1.866.730.7704 Fax 905.709.5255 1.888.738.9736