



# S120/277C-P Auxiliary Relay Pack Form C

120/277VAC Form C Auxiliary Relay Pack  
 General Purpose: (120 & 277) 20A NO/20A NC  
 Fluorescent Load: (120 & 277) 20A NO/10A NC  
 Incandescent Load: (120) 15A NO/2A NC  
 Motor Load: (120) 1 HP NO/1 HP NC, (277) 2 HP NO/2 HP NC



Installation Instructions


CAUTION


**TURN POWER OFF AT THE CIRCUIT BREAKER BEFORE  
INSTALLING POWER PACKS OR AUXILIARY RELAY PACKS.**

**ONLY QUALIFIED ELECTRICIANS SHOULD INSTALL THIS UNIT.**

The relay pack attaches to existing junction boxes. All low voltage wiring should be at least 22 gauge wire. All high voltage connections should be at least 14 gauge. Always check local building codes. After initial wiring is complete, verify that all wiring is correct. Improper wiring can damage the relay pack, power pack, lighting system and occupancy sensor.



www.wattstopper.com  
 Santa Clara, CA 95050  
 Technical Support: 800.879.8585