

## 2", 3", 4", 5" & 6" REGRESSED MINI PANEL 5 CCT SELECTABLE - SQUARE TRIM

LR22637, LR22638, LR22640, LR22642, LR22644

PLEASE CONSULT A QUALIFIED ELECTRICIAN FOR HANGING FIXTURE AND WIRING.

**CAUTION:** BEFORE STARTING THE INSTALLATION, DISCONNECT THE POWER BY TURNING OFF THE CIRCUIT BREAKER OR BY REMOVING THE FUSE AT THE FUSE BOX. CAREFULLY UNPACK AND IDENTIFY ALL PARTS BEFORE INSTALLATION.

### WARNING

FOR SAFETY, READ AND UNDERSTAND INSTRUCTIONS COMPLETELY BEFORE STARTING INSTALLATION. ELECTRICITY SHOULD BE TURNED OFF AT THE FUSE OR THE CIRCUIT BREAKER BOX BEFORE INSTALLING THE FIXTURE. ALL ELECTRICAL CONNECTIONS MUST BE IN ACCORDANCE WITH ELECTRICAL AND LOCAL ELECTRICAL CODE.


### CAUTION

DISCONNECT POWER BEFORE CONNECTING TRIM TO HOUSING, FAIL TO DO SO MAY PERMANENTLY DAMAGE THE LED.


#### TOOLS REQUIRED

- SAW
- MEASURING TAPE
- ELECTRICAL WIRING (USE AND GAUGE SUITABLE FOR APPLICATION TO CONNECT THE FIXTURES.)

1. MAKE A HOLE IN THE CEILING BY USING THE CUTOUT TEMPLATE. FIG. 1



2. CONNECT THE WIRE AS FIGURE 2 AND MAKE SURE INSULATION PROTECTION, THEN PULL THE FIXTURE SPRINGS IN VERTICAL DIRECTION.



3. PUSH THE FIXTURE INTO THE CEILING HOLE AND MAKE SURE IT IS A FIT.

